

FOR-X

Owner's Manuel

X-4260BT

CAR MP3 SYSTEM



www.for-x.com.tr



FOR-X

X-4260BT

WARM NOTICE

Thank you for purchasing our products, car audio system.Before installing or operating this unit, please read the instruction manual so that you can make better use of your unit, and keep these instructions for future reference.

- 1.Do not repair the unit in case of breakdown.Power off the player and contact with your local dealer at once.The unit belongs to precision instruments with complicated electronic components. Improper repairment may damage the unit or worsening the problem.
- 2.Do not put the unit in moisture, dusty, or direct sunlight environment etc.
- 3.Do not clear the unit with chemical cleanser but soft cloth
- 4.Do keep the unit away from overheating or super cooling position. This unit store degree environment is-10 C to 60 C .
- 5.Do avoid from dropping and heavy shock

INSTRUCTION

⏻/MOD

Power on/Power off.

Under power on state, short press for shifting among RADIO-USB-SD-AUX-BT(Bluetooth function is optional)

Big Knob/SEL

Roating for adjust Volume +/Volume-

Short press for select BAS-TRE-BAL-FAD-EQ(JAZ/CLASS/POP) -LOUD-ST 1/PAUSE

On SD or USB mode, press for pause, press again for continue.

2/INT: Music Browse

Press“INT”, you will see“INT”on the LCD and it will play each songs for only 10 seconds in order.Second time press will stop music browse and playback normally.

3/RPT: Repeat

Press“RPT”, you will see“RPT”on the LCD and it will repeat the same music, once again press will stop repeating.

4/RDM: Random Playing

Press.“RDM”, you will see“RDM”on the LCD and all the songs will be played in random, once again press will stop this function.

5/-10: Short press skip10songsbackwardly, Long press trans ter document backwardly.

FOR-X

X-4260BT

6/+10: Short press skip 10 songs forwardly, Long press transfer document forwardly.

AMS: Station Automatically Seeking

On radio mode, press“AMS”, it will automatically seeking the stations and stay on each station for 5 seconds.During these 5 seconds, you can press it again for staying on the station that you like.Press“APS”for more than 3 seconds, it will clear previous station memory and re-seek and store new stations with your operation.Once again press on“AMS”will stop stations storage.

BAND: Radio transition

Press“BAND”for selection among FM 1, FM 2, FM 3, AM 1, AM 2 (AM function is optional)

DISP/CLK: Time display and adjustment

a) After installation of this unit, you will see the radio frequency on the LCD with power on

b) Press“DISP/CLK”, you can see time display on LCD.rotate the knob for HOURS and adjustment

c) Press the knob will skip to MINS adjustment

d) Press“DISP/CLK”again after time adjustment to lock the time memory.

RESET: Back to factory default

In case of any error appear; use a small pinto insert the small hole for back to factory default.

EQ: Pop/Rock/Classical funtion

Audio Controller: BAS/TRE/LOUD/FAD

LOC/DX: Transfer coding, when using radio can select

ST/MONO: Stereo and Mono

↶/↷ Bluetooth, Phone answer or hangup(Bluetooth function is optional)

BLUETOOTH: (Bluetooth function is optional)

Mobile phone open bluetooth function and search the bluetooth signal which name“CAR BT”and connect.After connected successfully it wil show“BT ON in the LCD display, after set we can use bluetooth to play music and answer or hangup the phone

FOR-X

X-4260BT



57,4mm


197,4mm

High Power MP3/Radio Wiring Illustration

- 1.Rear Right+ [purple]
- 2.Front Right+ [Gray]
- 3.Front Left+ [White]
- 4.Rear Left+ [Green]
- 5.Rear Right- [purple and black]
- 6.Front Right- [gray and black]
- 7.Front Left- [white and black]
- 8.Rear Left- [Green and black]

- 11 Automatic antenna [blue]
- 12 ACC+12VDC [Red]
- 14 Battery + [Yellow]
- 16 GND [Black]

- 17 FL-OUT [White]
- 18 RL-OUT [White]
- 19 FR-OUT [RED]
- 20 RR-OUT [RED]
- 21 Radio-ANT



LINE CONNECTION

Speaker connection

The unit is suitable for the connection of car speaker from 4ohm to 8ohm.Do disconnect the power cable before speakers connection finish to avoid short circuit.Avoid touching between speakers'cables and ground cable or it will destroy the ground line.Connect the black line to the ground or the metal part of the car body

Power line connection

First, directly line the power memory cable of yellow to +12V power, then goes on with other cables connection.When all the connection finish, finally connect the red cable to ACC of the car.

Antenna Connection

Insert the radio antenna to the access port on the unit

Important Notice

If the fuse bread down means there is line connection problem with potential dangerous.Then do make a careful check of all the connection to avoid further problem.

FOR-X

X-4260BT

APP CONTROL

Android QR code



IOS QR code



1. Mobile phone installation (iCar Link) APP, directly search (iCar Link) in the application store to download and install, or WeChat scan the QR code to download and install.
- 2.(Icar Link) Connect via Bluetooth, you can control it on the phone after connecting: power/radio/USB/SD/AUX/ Bluetooth music/EQ/volume

Connection method:

1. The phone is connected to the car's Bluetooth.
2. Go to the mobile application and click "Connect" in the upper right corner to configure the connection.

FOR-X

X-4260BT

REMOTE CONTROL



Precaution:

1. Under normal conditions, the battery life of remote control is about 6 months. When remote control doesn't work well, check and replace with a new battery timely.
2. When the remote control is not to be used for a long time, please remove the battery to avoid liquid leakage which may damage the remote control
3. Prevent falling from a height to avoid damage.
4. The battery is forbidden to be disassembled nor heated nor put into fire nor placed together with other metals.
5. Place the battery in a safe place to prevent the kid from swallowing it. In case the kid swallowed the battery, immediately send him/her to see a doctor.

Button Name	Button Function
⏻	Power ON/OFF
MODE	Mode conversion
⏸	Mute
SEL	Enter EQ setup menu
EQ	EQ switching
⏮/⏭	In disc mode, select previous/next chapter/ track; in radio mode, seek lower/higher frequencies
VOL-/VOL+	Decrease/increase volume
BAND	In radio mode, select bands
AMS	press scan
1, 2, 3, 4, 5, 6, 7, 8, 9, 0	Select current band, section or preset stations; Input phone numbers, etc.



www.for-x.com.tr

